

M40098.V01 axial elasticity measuring unit

M40098.V02 Additional analysis of the inclination characteristic curve

Contents:	Page
1. Functions	2
1.1 Measurement task	2
1.2 Representation of the results of measurement	2
2. Construction	2
3. Connection and control elements	3
4. Programming	
4.1 F1 inputs	4
4.2 F2 store measured values on floppy disk	5
4.3 F3 store diagnostic data on floppy disk	5
4.4 F4 store program on floppy disk	5
4.5 F5 install program of floppy disk	5
4.6 F8 zeros	5
5. Operating mode	6
6. Connection diagrams	7
Security comments according to VDE 0411	11

1. Functions

1.1 Measurement task: examination of the axial elasticity of axial joints.

Elasticity is measured by push and pull load with a programmable tester and checked at compliance with its tolerance:

1.2 representation of the results of measurement

The measured value is announced as a numerical value. In addition, the result of grouping is announced, therefore GOOD or NOT GOOD.

Additionally, the signal response of axial movement is represented as a wave form over the time axis:


2. Construction

- Measuring computer QP300: 486DX/66; 4MB RAM; 540MB Harddisk;
3,5" Floppy-Disk 1,44MB
monochrome VGA Display
32 I/O Optocoupler
1x DMS-, 1x inductive, 1x analogue measuring input
Num. Keyboard
- Case 2/3 19", 4HE



3. Connection and control elements

Reverse of the case:



- | | |
|--------------------------------|--|
| (1) X401 Europlug power supply | input 230V/50Hz |
| (2) X402 9pol. socket MIN D | test socket |
| (3) X404 5pol. socket DIN | keyboard entry |
| (4) X403 25pol. socket MIN D | printer exit |
| (5) X405 9pol. plug MIN D | serial interface |
| (6) X314 9pol. socket MIN D | pro bus interface |
| (7) X315 6pol. socket 680: | exit to servo valve |
| (8) T1-4/1 5pol. socket 680: | input load cell |
| (9) T1-4/2 5pol. socket 680: | input way stylus |
| (10) T1-4/3 5pol. socket 680: | input way for carriage position 0..10V |

4. Programming

Turn on device. After loading the program, the device is in the operating mode AUTOMATIC and therefore ready to operate, if the drive cover is closed. In order to be able to carry out inputs the lid must be opened. As a result, it is changed to SETUP.

The sub-operating modes appear in the menu bar:

- F1 inputs
- F2 store measured values on floppy disk
- F3 store diagnostic data on floppy disk
- F4 store program on floppy disk
- F5 install program of floppy disk
- F8 zeros

4.1 F1 inputs

key * = Escape settings

Possible for selection only after opening the concluable drive cover!

The ratings are entered in the input fields in sequence. The jump into the next field occurs by double pressing the press button ENTER.

If the respective value is set aside darkly, he can be retyped directly by input of the new value. If only ENTER is entered, the old value is maintained.

After all fields were processed, the input menu is left automatically again.

Meaning of the individual input fields:

Axial elasticity UL: upper tolerance limit for the axial elasticity
Axial elasticity LL: lower tolerance limit for the axial elasticity

Axial elasticity offset: Correction constant factor for the axial elasticity in order to correct mechanical offset
Nominal force: Peak value of force for pull and push in kg
period: Time of a pull/push cycle in seconds
No. of conditioning: Number of pull/push cycles before the measuring cycle
Kp: Proportional part of the PID controller
Ki: Integral part of the PID controller
Factor(kp+ki): Sum factor

4.2 F2 store measured values on floppy disk

Possible for selection only after opening the concludable drive cover!

Storage of the measured values occurs here in the PROCON format. The measured value floppy disk must contain a valid PROCON test flow chart.

The features are arranged as follows:

Channel	feature	-----
1	axial elasticity	MAX-MIN value

4.3 F3 store diagnostic data on floppy disk

Selection possible only after opening the concludable drive cover!

In the case of technical problems intern expiry dates can be transmitted for analysis on floppy disk.

4.4 F4 store program copy on floppy disk

Selection possible only after opening the concludable drive cover!

The current programme version and the parameters are transmitted onto floppy disk.

4.5 F5 load program from floppy disk

Selection possible only after opening the concludable drive cover!

The backup of the parameters and/or the installation of a new programme version occurs here. This becomes only effective during the new start of the computer.

4.6 F8 zeros

Selection possible only after opening the concludable drive cover!

The force actual value is set to zero.

5. Operating mode

M40098.V01


Axial elasticity measuring unit [App.#3 40098170.TST]			
Inputs	Outputs	settings	result
Start <input type="radio"/>	startposition <input type="radio"/>	Axial UL ym 75	drawing no. 030.261.071.504
peg clamped <input type="radio"/>	clamp peg <input type="radio"/>	Axial LL ym 32	description Traglenker.Teil1
ready <input checked="" type="radio"/>	tracer free <input type="radio"/>		No. of values 100
RESET <input type="radio"/>	intermediate position <input type="radio"/>	Nominal force kg 300	Axial ym 25
			Classification LL
Position act.val. mm 75.475	model-no. 1	period sec. 0.5	Axial ym <input type="button" value="Inspect"/>
tracer act.val. ym -0.1	step	no. of conditioning 1	
force act.val. N 4	SETUP <input checked="" type="radio"/>	Offset Position 75	
<p>Arndt & Voß M40098.V01 F4:backup Program to disk F5:restore Program from disk Version: 170 F1:settings F2:meas.val. to disk F3:chart to disk F8:force set Zero / Statistik position: F6:UP F7:DOWN STORE: F9:SET position</p>			


M40098.V02

Axial elasticity measuring unit [App.#2 40098219.TST]			
Inputs	Outputs	settings	result
Start <input type="radio"/>	startposition <input checked="" type="radio"/>	Axial UL ym 75	drawing no. 030.261.071.504
peg clamped <input type="radio"/>	clamp peg <input type="radio"/>	Axial LL ym 32	description Traglenker.Teil1
ready <input checked="" type="radio"/>	tracer free <input type="radio"/>		No. of values 100
RESET <input type="radio"/>		Nominal force kg 300	inclination % 45
			Axial ym 25
			Classification LL
Position act.val. mm 75.45	model-no. 1	period sec. 0.5	course of force <input type="button" value="Inspect"/>
tracer act.val. ym -0.1	step -10	no. of conditioning 1	
force act.val. N 0.4	SETUP <input type="radio"/>	Offset Position 75	
Arndt & Voß M40098.V02 Version: 219 F4:backup Program to disk F5:restore Program from disk F1:settings F2:meas.val. to disk F3:chart to disk F8:force set Zero position: F6:UP F7:DOWN STORE: F9:SET clamp position F10: SET start position			

The measuring computer waits for the starting signal from the SPS.
 The following sizes are announced:
 Measured value and grouping of the axial elasticity
 The measured value process of the way of the former measurement STATUS:
 0: Measure ready

6. Junction diagrams





Arndt & Voß GmbH Eichhofstr. 7 - D 21255 Tostedt http://www.arndtundvoss.de Tel. ++49 (0) 4182 289 -760 Fax. -761 email: arndtundvoss@t-online.de	Axialspielseinheit
Größe: A Maßstab:	Datum: 06.04.2001 at CAD-Nr. 4_98V2b2
	Artikel-Nr. M40098.V01-V04 Rev. 0 Seite 2 von 2

Security comments according to VDE 0411

General technical

time for warming up	20 minutes
temperature	0...+40 Grd C
atmospheric humidity	on to 75% rel.
frequency	50/60 Hz
power supply voltage	230V +/-10%
security	according to VDE 0411, protection class 1

This unit is built and checked under DIN 57411 part 1/VDE 0411 part 1 and left the factory in a safe and perfect condition. To preserve this condition and to guarantee a safe working the user has to follow the comments and warnings which are given in this instructions.

Before turning on the power you have to make sure, that the voltage of operation and the mains voltage correspond.

The mains plug may only be inserted into a socket with ground contact. The safety effect may not be abolished by an extension lead without ground connection.

The opening of covers or removing of components, except if it is possible to do by hand, might uncover parts or connections under dangerous voltage.

Racks may only be used inside a cover.

If an adjustment, a maintenance or a repair at the opened unit under voltage is unavoidable, it may be done only by a qualified employee, who is well acquainted with the dangers involved.

ATTENTION:

After the end of those works, the unit has to be checked according to VDE 0411, part 1.

You have to make sure, that only fuses of the given type and values are taken for replacement. The use of mended fuses or short-circuiting them is inadmissible.

If it is presumed, that a safe work is not possible, you have to take this unit out of work. A safe work may not be possible, if

- there are visible damages at the unit.
- the unit doesn't work.
- after longer storage under unfavourable circumstances.
- after heavy stress of transport.